



promate.net Lifestyle Technology

**bluRock2**

# Bluetooth™ Mini Speaker with Mic, AUX Input and Smartphone Power Bank



Bluetooth (2.1)



Handsfree



AUX Input Jack



Microphone



Intelligent  
Voice Prompt



Charging station



## User Guide

# Introduction

Thank you for purchasing Promate bluRock2 is a portable Bluetooth™ speaker which combines multiple functionalities, all packed in one mini-sized device. Pair bluRock2 with mobile, smartphone, tablet or notebook for music and audio streaming. Ideal when watching movies or listening where sound prefers to be louder on a broader environment. Receiving phone call when away from the mobile is also possible with its in-built Handsfree feature using a highly sensitive mic for a clear and crisp voice feedback. bluRock2 also comes with humanized intelligent voice prompt feature. Place bluRock2 on the power back up battery charging base and you can enjoy additional hours of music anywhere. What's more, the charging output will pump up your smartphone and prolong the battery level on the go.




## Features

- Mini portable ideal for watching movies or listening to music on mobiles and tablet devices
- Compatible with all Bluetooth enabled mobile and tablet devices
- Handsfree function with ultra-sensitive high quality microphone
- Comes with in-built Aux input and wireless charging base for extra power
- Enhanced in-built amplifier and extendable speaker design for fantastic sound quality
- Custom-tuned vacuum bass for low frequency response
- Light-weight and portable, pocket-sized
- Power back up battery switch for the speaker or USB chargeable smartphones
- Made from ABS plastic material

## Packaging Contents

- bluRock2
- Micro-USB cable
- Micro-USB to Female USB charging Cable
- Audio cable
- User Guide
- Warranty card

## Appearance and Interface Description



## No.Name

- 1 Play/Pause button: Press to play or pause the music; Press and hold for Bluetooth™ pairing
- 2 Volume buttons: Press to decrease the volume and press to increase.
- 3 Speakerphone button: Once the Bluetooth™ smartphone is paired, press once to answer the phone call or press it to end a call.
- 4 Status indicator: Blue light flashes slowly – turning on the speaker  
Blue light flashes fast – On Bluetooth™ pairing mode  
Red light – On Aux-in model
- 5 Microphone
- 6 Power switch for the speaker: Green if it's ON and Red if it's OFF.
- 7 Audio Aux port: Use audio cable provided for external music players
- 8 Power Switch: Toggle the power switch left to "PS" to charge USB chargeable mobile device or to "CH" for charging bluRock2

## Instructional Usage

### Bluetooth™ pairing

- Turn the power switch on the bottom of speaker then prompt tone will mention “bluRock2 is ready, waiting for device pairing”.
- Turn on the Bluetooth™ device on your phone or tablet, and search “bluRock2” and pair. Password is 0000. When successfully paired, "It is paired" prompt sound comes out. Play music from your phone or tablet.
- Adjust the volume by pressing the Volume +/- buttons on the top of speaker. Press the Play/Pause button to play or pause the tune. Press and hold the Play/Pause button to turn on/off the Bluetooth.
- Handsfree function. When there is an incoming call, the speaker will mention the number automatically, then just press the Phone/ handsfree button to answer the phone call or end the call. After the call ends, the speaker will continue playing the interrupted music.
- Power off. When not in use, please turn off the switch to red status to prevent the waste of power.

## Charging the speaker

- Charging the speaker using the power station: Turn the switch to CH, then put the speaker on the spare power station correctly and connect the USB cable to the computer or a 5V/1A power adaptor.
- Then power indicator:
  - Red: means the speaker main unit is under charging.
  - Blue: means the speaker spare power station is under charging (Speaker unit power is full).

## Charging a USB chargeable mobile device:

- Charging the speaker using the power station:  
Turn the switch to PS, then put the Micro-USB to Female USB charging cable on the spare power station correctly and connect to the mobile device for charging.

## Playing music:

- Connect an audio aux in cable to the Audio input on the speaker and on an external audio output such as MP3 players.
- Speaker will switch to Line-in mode automatically.
- Press the Vol-/ + button or native controls on the connected MP3 player to control volume.
- Press Play/Pause on the speaker to play/pause the tune.  
Or just control the tune by press Play/Pause on the MP3 player.

## Troubleshooting

Symptom	Possible problem and solution
Cannot pair successfully	<p>Check the speaker is in standby and searching mode.</p> <p>Check whether there are too many Bluetooth™ receivers around your Bluetooth™ device. Turn off them to avoid any disturbance. And pair again.</p>
Low sound or distorted	<p>Check the volume setting on both the speaker and your Bluetooth device and adjust the volume to a suitable level.</p>
Cannot play properly, the music is intermittent	<p>Check whether the distance between the speaker and your Bluetooth™ device is out of its working distance, or whether there are some obstacles block the communication between the speaker and the Bluetooth™ device.</p>
Under Bluetooth™ mode, THE STATUS LED is off	<p>Probably it is power shortage, please charge the speaker.</p> <p>Press and hold the Play/Pause button to turn off the Bluetooth™, then press and hold the Play/Pause button to turn on the Bluetooth™, re-pair the speaker with the Bluetooth™ device.</p>

## Precautions

Please read this User Guide carefully before using the product.

The contents herein may be changed to deliver the better services to the end-user. To keep the perfect performances of the product, never use it in cold, hot, dusty or moistened areas or places, especially in the following conditions:

- 1 .Moist or underwater conditions.
2. Conditions near the heater or high-temperature service.
3. Conditions with direct sunshine.
4. Conditions with apt falling.
5. Never dismantle the charge and sync cable without due permission, otherwise it may nullify the warranty clauses.





[www.promate.net](http://www.promate.net)